

MARS T1000


TALLY Signal Universal Converter User Manual



Hollyland Technology

MARS T1000

TALLY Signal Universal Converter Accesories



MARS T1000 Tally Cable:

One side is DB25PIN and the other side can be customized according to the switcher

TALLY Connection Instruction



TALLY Signal Universal Converter can be connected to any Type-A port on side of the main station by converter.

Remark: Do not connect the Type-C port

The DB25 connector of TALLY Signal Universal Converter can be connected to DB25 connector of TALLY Cable. The other side of TALLY Cable need to be connected to switcher

DB25 INTERFACE AND TALLY INDICATOR WIRING RELATION TABLE

Channel	Program	Preview	GND
Tally 1	PIN1	PIN14	PIN13
Tally 2	PIN2	PIN15	
Tally 3	PIN3	PIN16	
Tally 4	PIN4	PIN17	
Tally 5	PIN5	PIN18	
Tally 6	PIN6	PIN19	
Tally 7	PIN7	PIN20	
Tally 8	PIN8	PIN21	

TALLY Working Diagram



MARS T1000 Support Dual Color TALLY Light

Switchers Supporting Dual Color TALLY: Datavideo HS2800, Panasonic AV-HS410MC etc.

Switchers Supporting Single Color TALLY: SONY MX-500; SONY AWS-750 etc.

FAQ

1. Why TALLY light is not on when it was connected correctly?

A: a. Check if TALLY is connecting to main station with Type-A; do not connect to Type-C port

b. Make sure the product is the right version as below:

Main Station: 1.0.6.12 Beltpack: 1.2.4.0

c. Check the tally output type is electrical level or break-make level, and choose “High” or “low” switch accordingly

2. MARS T1000 supports dual color TALLY light, then why there are some switchers can only show single color Tally?

A: Because those switchers only support single color Tally, like SONY MCX-500; SONY AWS-750 ETC. If switcher can support dual color Tally, then MarsT1000 can work as normal.

3. Can Tally function works normally when two MARS T1000 connected?

答: Temporarily unavailable.

FAQ

4. What is the reason of the red and green light flash randomly or stay on?

A: Normally, it caused wrong connection of TALLY cable . Please check TALLY cable sequence , and if there is short circuit or omitted.

5. BMD Switcher Using Note

A: 1. Switchers default IP is 192.168.10.240, pls do not change if necessary.

2. It is recommended to use the Tally Converter from original factory, because others may cannot connect to switchers.

6.For SONY MCX-500 switcher, why TALLY was working abnormally while transmitting video signal from SDI to HDMI?

A: SONY MCX-500 TALLY pin definition was divided into SDI and HDMI signal, so when signal is converted from SDI to HDMI, TALLY cannot work normally.

7. Can MarsT1000 be connected to other wired or wireless intercom system?

A: Yes